

Dig Specs

Septic Tanks

Size of Tank	Dig Hole		Actual Measurements	
	Width	Length	Inlet	Height
500	4' 6"	7' 6"	4' 1"	5' 0"
750	5' 6"	9' 9"	3' 1"	3' 11"
1000	6' 7"	9' 0"	4' 1"	5' 0"
1000 LOW	6' 0"	11' 0"	3' 6"	4' 6"
1200	6' 0"	11' 0"	4' 8"	5' 10"
1500	6' 0"	11' 0"	5' 6"	6' 6"
1500 LOW	6' 0"	13' 0"	4' 1"	4' 11"
2400	6' 0"	11' 0"	7' 10"	8' 6"

Lift Stations

Size of Tank	Dig Hole		Actual Measurements		
	Width	Length	Inlet	Height	w/ Riser
500	4' 0"	8' 0"	4' 1"	5' 0"	6' 3"
1000	6' 7"	9' 0"	4' 1"	5' 0"	6' 3"
1200	6' 0"	11' 0"	4' 8"	5' 10"	7' 1"

NORWECO Installation Data

Tank	Dig Hole			Actual Measurements		
	Width	Length	Depth	Width	Length	Depth
500 GPD	6' 6"	10' 3"	8' 0" **	5' 6"	9' 3"	7' 4" *
750 GPD	6' 6"	10' 6"	6' 0" **	5' 6"	9' 3"	8' 4" *
Chlorinator	4' 0"	5' 6"	25" ***	2' 10"	4' 2"	3' 0"

* Includes 16" aerator housing - add extra riser sections as needed to bring top to finish grade

** Beneath the flow line of house sewer

*** Above the bottom of aeration tank hole

Bottom of all holes must be level! Backfill excavation and fill all tanks with water.

updated October 8, 2007